

- 1. 2/0 BARE COPPER GROUND-ING WIRE TO BE PLACED UNDER PAD BEFORE PAD IS POURED AND TO BE CONTINUOUS.
- 2. WIRE TO BE BONDED TO GROUND RODS WITH HEAVY BOLTED CLAMP.
- 3. LEAVE SLACK IN BARE CU GROUND WIRE IN HIGH AND LOW SIDE CAVITIES FOR PES TO ATTACH TO:
- 4. INSTALL CONDUIT GROUND-ING BUSHING FOR EACH STEEL PRIMARY CONDUIT.
- 5. ALL MATERIAL ON THIS SHEET TO BE FURNISHED BY CUSTOMER UNLESS OTHER-WISE SPECIFIED.

## Note:

This spec is to be used in conjunction with the general 3phs pad spec.

## PULASKI ELECTRIC SYSTEM TYPICAL FOR CONCRETE PAD

Location:					
<u>Trans. 225-300kva</u>		Gal. oil	163_	LB	
Maker Ermco		Manufacture date			
S/N					
Voltage 120		Т	aps no		
%Z 1.5_	Fault (	Current _		_	