

- 1. 2/0 BARE COPPER GROUND-ING WIRE TO BE PLACED UNDER PAD BEFORE PAD IS POURED AND TO BE CONTINUOUS.
- 2. WIRE TO BE BONDED TO GROUND RODS WITH HEAVY BOLTED CLAMP.
- 3. LEAVE SLACK IN BARE CU GROUND WIRE IN HIGH AND LOW SIDE CAVITIES FOR P.E.S. TO ATTACH TO.
- 4. INSTALL CONDUIT GROUND-ING BUSHING FOR EACH STEEL PRIMARY CONDUIT.
- 5. ALL MATERIAL ON THIS SHEET TO BE FURNISHED BY CUSTOMER UNLESS OTHER-WISE SPECIFIED.

## Note:

This spec is to be used in conjunction with the general 3phs pad spec.

## PULASKI ELECTRIC SYSTEM TYPICAL FOR CONCRETE PAD

Location:					
<u>Trans. size</u>	1000KVA	Gal. oi		LB	
/ 1500KVA / 2000KVA Manufacture date					
S/N					
Voltage 277/480			Т	aps no	
%Z 1.5_	Fault (	Current			